



JOHN DEERE

# Product Services Information

## INSTALLATION INSTRUCTIONS

(Includes English, French, German, Spanish and Italian)



JOHN DEERE

### PAIL HOLDER KIT

---

#### Parts in Kit

Qty.	Description
1	Bucket Holder Assembly

**NOTE:** *Bucket is not supplied with kit.*


**Retain these installation instructions with the machine operator's manual.**

#### Parking Safely


1. Stop vehicle on a level surface, not on a slope.
2. Lock park brake.
3. Stop engine.
4. Remove key.
5. Before you leave the operator's seat, wait for engine and all moving parts to stop.
6. Disconnect the negative battery cable or remove the spark plug wire (for gasoline engines) before servicing the machine.

#### Install Kit

1. Park machine safely. (See Parking Safely.)



MX28372



MX28373

2. Install bucket holder assembly (A) on cargo box tube (B) or cargo rack tube (C) using clamp (D).
  - Bucket must sit on cargo box or cargo rack. Holder is only to be used to prevent bucket tipping over.
3. Position bucket against holder and secure with rubber strap (E).